



# MIGHTY LUBE® CLEANING BRUSHES

## For 4" I-Beam Conveyors

### INCLUDED IN THIS PACKAGE

#### MODEL 40Y Yoke Cleaning Brush Brush Assembly for 4" I-Beam

- Removes buildup from hard to reach, often overlooked sources of contamination
- Mounting block welds to the bottom of the rail
- Brush is easily replaced



\*Yoke Brush shown installed on rail.

### ALSO AVAILABLE:

#### I-Beam Conveyor Chain Cleaner

- Cleans chain and trolleys
- Removes debris and reduces rejects without contaminating parts
- Adjusts to contact hard to reach points
- Spring loaded to prevent jamming if a hanger passes at an odd angle



MODEL #400-I  
For Four Inch I-Beam

#### Beam Sweep

- Cleans the web surfaces of the rail
- Reduces debris fall out and improves grounding contact
- Easily installed and removed



MODEL #4-91BC  
For Four Inch I-Beam

\*4-91BC Shown  
Installed on Rail

See our website for information on **Powered Cleaners** as well as other Mighty Lube Equipment.



**MIGHTY LUBE®**  
Systematic Lubrication, Inc.

[WWW.MIGHTYLUBE.COM](http://WWW.MIGHTYLUBE.COM)

9569 W 40TH ST • FREMONT, MI 49412 | PHONE 231-924-6160



# 40Y YOKE BRUSH INSTRUCTIONS



## MODEL #40Y PARTS

(1) 01YB      Mounting Block Assembly  
w/ Allen Screw


### REPLACEMENT BRUSH:

(1) B40RB

## INSTALLATION

*Complete assemblies are shipped  
with brushes pre-assembled*

1. IMPORTANT! Direction of travel is critical to the proper function of the brush. Determine the direction of travel.
2. Center the mounting block on the bottom of the I-Beam.
3. Weld in place as shown in the illustration.



**MIGHTY LUBE®**  
Systematic Lubrication, Inc.

9569 W 40TH ST • FREMONT, MI 49412 | PHONE 231-924-6160

[WWW.MIGHTYLUBE.COM](http://WWW.MIGHTYLUBE.COM)